

**AS SHIPPED BREAKDOWN****SEPTEMBER 06, 2012**For Help Desk Phone Numbers [Click here](#)

Part Number: 3626461

Description: ENGINE AR-COMPL

Change Level: 02

| <a href="#">Reference Number</a> | Qty  | Add Remove | Description      | Service Ind. | Set Type   | Note | BreakDown                    |
|----------------------------------|------|------------|------------------|--------------|------------|------|------------------------------|
| 0K5581                           | 0001 |            | SETTING          | N            | REQUIREMEN | B    | <a href="#">BreakDown...</a> |
| 4N2481                           | 0001 |            | FASTENER GP      | N            | PTS-LIST   | J    | <a href="#">BreakDown...</a> |
| 4P5894                           | 0001 |            | DAMPER GP-PUL &  | N            | PTS-LIST   | F    | <a href="#">BreakDown...</a> |
| 4P6846                           | 0001 |            | FASTENER GP      | N            | PTS-LIST   | F    | <a href="#">BreakDown...</a> |
| 5P2506                           | 0001 |            | LITERATURE GP    | N            | PTS-LIST   | SL   | <a href="#">BreakDown...</a> |
| 6I3638                           | 0001 |            | DRIVE GP-PUMP    | N            | PTS-LIST   | F    | <a href="#">BreakDown...</a> |
| 6N9159                           | 0001 |            | V-BELT ST        | Y            | PTS-LIST   | F    | <a href="#">BreakDown...</a> |
| 7N3060                           | 0001 |            | FLYWHEEL GP      | N            | PTS-LIST   | G    | <a href="#">BreakDown...</a> |
| 9N3889                           | 0001 |            | COVER GP         | N            | PTS-LIST   | G    | <a href="#">BreakDown...</a> |
| 1074447                          | 0001 |            | INST - TURBO     | N            | REQUIREMEN | XC   | <a href="#">BreakDown...</a> |
| 1076736                          | 0001 |            | COVER GP         | N            | PTS-LIST   | D    | <a href="#">BreakDown...</a> |
| 1082312                          | 0001 |            | FITTING GP       | N            | PTS-LIST   | M    | <a href="#">BreakDown...</a> |
| 1091657                          | 0001 |            | FASTENER GP      | N            | PTS-LIST   | E    | <a href="#">BreakDown...</a> |
| 1092373                          | 0001 |            | FASTENER GP      | N            | PTS-LIST   | K    | <a href="#">BreakDown...</a> |
| 1108876                          | 0001 |            | FILLER GP-OIL    | N            | PTS-LIST   | J    | <a href="#">BreakDown...</a> |
| 1112088                          | 0001 |            | LIFTING GP       | N            | PTS-LIST   | G    | <a href="#">BreakDown...</a> |
| 1165399                          | 0001 |            | CLAMP KIT        | N            | PTS-LIST   | SL   | <a href="#">BreakDown...</a> |
| 1204231                          | 0001 |            | DRIVE GP-FAN -D  | N            | PTS-LIST   | F    | <a href="#">BreakDown...</a> |
| 1209100                          | 0001 |            | MOTOR GP-ELECSTG | N            | PTS-LIST   | N    | <a href="#">BreakDown...</a> |
| 1209847                          | 0001 |            | COVER GP         | N            | PTS-LIST   | F    | <a href="#">BreakDown...</a> |
| 1240657                          | 0001 |            | SHIELD GP-MANF-A | N            | PTS-LIST   | L    | <a href="#">BreakDown...</a> |
| 1260079                          | 0001 |            | LINES GP-AIR     | N            | PTS-LIST   | L    | <a href="#">BreakDown...</a> |
| 1270564                          | 0001 |            | LIFTING GP       | N            | PTS-LIST   | F    | <a href="#">BreakDown...</a> |
| 1275728                          | 0001 |            | COVER GP         | N            | PTS-LIST   | G    | <a href="#">BreakDown...</a> |
| 1340597                          | 0001 |            | CONT GP -B       | Y            | PTS-LIST   | SL   | <a href="#">BreakDown...</a> |
| 1357634                          | 0001 |            | HOUSING GP-FLY   | N            | PTS-LIST   | G    | <a href="#">BreakDown...</a> |
| 1358015                          | 0001 |            | PLUG GP          | N            | PTS-LIST   | G    | <a href="#">BreakDown...</a> |
| 1409746                          | 0001 |            | COVER GP         | N            | PTS-LIST   | D    | <a href="#">BreakDown...</a> |
| 1504279                          | 0001 |            | PUMP GP-F XFR&-C | N            | PTS-LIST   | M    | <a href="#">BreakDown...</a> |
| 1582770                          | 0001 |            | PULLEY GP-AUX DR | N            | PTS-LIST   | F    | <a href="#">BreakDown...</a> |
| 1596159                          | 0001 |            | COVER GP         | N            | PTS-LIST   | F    | <a href="#">BreakDown...</a> |
| 1599107                          | 0001 |            | CONNECTION GP -G | N            | PTS-LIST   | N    | <a href="#">BreakDown...</a> |
| 1599362                          | 0001 |            | DISPOSAL GP-FUME | N            | PTS-LIST   | J    | <a href="#">BreakDown...</a> |
| 1608329                          | 0001 |            | FASTENER GP      | N            | PTS-LIST   | J    | <a href="#">BreakDown...</a> |
| 1627456                          | 0001 |            | PAN GP-OIL       | N            | PTS-LIST   | J    | <a href="#">BreakDown...</a> |
| 1693345                          | 0001 |            | ALTERNATOR GP -B | Y            | PTS-LIST   | N    | <a href="#">BreakDown...</a> |
| 1701282                          | 0001 |            | FILTER GP-OIL -B | N            | PTS-LIST   | J    | <a href="#">BreakDown...</a> |
| 1727120                          | 0001 |            | FASTENER GP      | N            | PTS-LIST   | K    | <a href="#">BreakDown...</a> |
| 1804367                          | 0001 |            | FASTENER GP      | N            | PTS-LIST   | F    | <a href="#">BreakDown...</a> |
| 1871328                          | 0001 |            | COVER GP-MECH -A | N            | PTS-LIST   | E    | <a href="#">BreakDown...</a> |
| 1910583                          | 0001 |            | MANIFOLD GP      | Y            | PTS-LIST   | M    | <a href="#">BreakDown...</a> |
| 1915054                          | 0001 |            | PUMP GP-F PRM&-A | N            | PTS-LIST   | M    | <a href="#">BreakDown...</a> |
| 1943967                          | 0001 |            | MTG GP-SNSR      | N            | PTS-LIST   | N    | <a href="#">BreakDown...</a> |
| 2002852                          | 0001 |            | FASTENER GP      | N            | PTS-LIST   | K    | <a href="#">BreakDown...</a> |
| 2016631                          | 0001 |            | FITTING GP       | N            | PTS-LIST   | M    | <a href="#">BreakDown...</a> |
| 2045325                          | 0001 |            | COVERS GP-SHPG   | N            | PTS-LIST   | RC   | <a href="#">BreakDown...</a> |

|         |      |                  |   |            |    |                              |
|---------|------|------------------|---|------------|----|------------------------------|
| 2121487 | 0001 | LINES GP-TURBO O | N | PTS-LIST   | J  | <a href="#">BreakDown...</a> |
| 2129431 | 0001 | FILTER AS        | N | PTS-LIST   | M  | <a href="#">BreakDown...</a> |
| 2240754 | 0001 | FASTENER GP      | N | PTS-LIST   | J  | <a href="#">BreakDown...</a> |
| 2279495 | 0001 | SUPPORT GP-BRACE | N | PTS-LIST   | F  | <a href="#">BreakDown...</a> |
| 2295519 | 0001 | COVER GP         | N | PTS-LIST   | F  | <a href="#">BreakDown...</a> |
| 2299965 | 0001 | FASTENER GP      | N | PTS-LIST   | F  | <a href="#">BreakDown...</a> |
| 2299966 | 0001 | FASTENER GP      | N | PTS-LIST   | F  | <a href="#">BreakDown...</a> |
| 2349184 | 0001 | PLUG GP          | N | PTS-LIST   | E  | <a href="#">BreakDown...</a> |
| 2349706 | 0001 | PLUG GP          | N | PTS-LIST   | D  | <a href="#">BreakDown...</a> |
| 2349776 | 0001 | PLUG GP          | N | PTS-LIST   | E  | <a href="#">BreakDown...</a> |
| 2361780 | 0001 | CONT GP-MTG&     | N | PTS-LIST   | N  | <a href="#">BreakDown...</a> |
| 2374290 | 0001 | LINES GP-FILTER  | N | PTS-LIST   | M  | <a href="#">BreakDown...</a> |
| 2374291 | 0001 | MANIFOLD GP-EXH  | N | PTS-LIST   | L  | <a href="#">BreakDown...</a> |
| 2389384 | 0001 | FASTENER GP      | N | PTS-LIST   | N  | <a href="#">BreakDown...</a> |
| 2399957 | 0001 | SENSOR GP-LEVEL  | Y | PTS-LIST   | SL | <a href="#">BreakDown...</a> |
| 2423492 | 0001 | TURBO GP -A      | N | PTS-LIST   | L  | <a href="#">BreakDown...</a> |
| 2448681 | 0001 | SUPPORT GP-ENG   | N | PTS-LIST   | F  | <a href="#">BreakDown...</a> |
| 2478211 | 0001 | PLUG GP          | N | PTS-LIST   | D  | <a href="#">BreakDown...</a> |
| 2554214 | 0001 | INSTRUCTIONS -R  | N | REQUIREMEN | RD | <a href="#">BreakDown...</a> |
| 2559245 | 0001 | LINES GP-WATER   | N | PTS-LIST   | K  | <a href="#">BreakDown...</a> |
| 2559248 | 0001 | FASTENER GP      | N | PTS-LIST   | K  | <a href="#">BreakDown...</a> |
| 2559250 | 0001 | PLUG GP          | N | PTS-LIST   | K  | <a href="#">BreakDown...</a> |
| 2559251 | 0001 | PLUG GP          | N | PTS-LIST   | K  | <a href="#">BreakDown...</a> |
| 2559252 | 0001 | PLUG GP          | N | PTS-LIST   | K  | <a href="#">BreakDown...</a> |
| 2601544 | 0001 | COVER GP-SHPG    | N | PTS-LIST   | RC | <a href="#">BreakDown...</a> |
| 2692509 | 0001 | HOUSING GP-FRONT | N | PTS-LIST   | F  | <a href="#">BreakDown...</a> |
| 2708444 | 0001 | MTG GP-ALT       | N | PTS-LIST   | N  | <a href="#">BreakDown...</a> |
| 2826846 | 0001 | FASTENER GP      | N | PTS-LIST   | F  | <a href="#">BreakDown...</a> |
| 2831613 | 0001 | INSTRUCTION-FAN  | N | REQUIREMEN | XK | <a href="#">BreakDown...</a> |
| 2858628 | 0001 | FASTENER GP      | N | PTS-LIST   | F  | <a href="#">BreakDown...</a> |
| 2869120 | 0001 | FASTENER GP      | N | PTS-LIST   | N  | <a href="#">BreakDown...</a> |
| 3111441 | 0001 | PLUG GP          | N | PTS-LIST   | K  | <a href="#">BreakDown...</a> |
| 3568339 | 0001 | LUBRICANT GP     | N | PTS-LIST   | P  | <a href="#">BreakDown...</a> |
| 3588534 | 0001 | LINES GP-F FIL   | N | PTS-LIST   | M  | <a href="#">BreakDown...</a> |
| 3590900 | 0001 | GAUGE GP-O LEVEL | N | PTS-LIST   | J  | <a href="#">BreakDown...</a> |
| 3590920 | 0001 | WIRING GP-CONT   | N | PTS-LIST   | N  | <a href="#">BreakDown...</a> |
| 3592103 | 0001 | ENGINE AR-CORE   | N | PTS-LIST   | D  | <a href="#">BreakDown...</a> |
| 3605376 | 0003 | PAINT GP         | N | PTS-LIST   | P  | <a href="#">BreakDown...</a> |
| 3645465 | 0001 | INST-PAINT       | N | REQUIREMEN | XB | <a href="#">BreakDown...</a> |
| 3697970 | 0001 | ELBOW GP-AIR IN  | N | PTS-LIST   | L  | <a href="#">BreakDown...</a> |

**Total Parts: 86**

Caterpillar Confidential: **Green**

Content Owner: Shane Gilles

Web Master(s): [PSG Web Based Systems Support](#)

Current Date: Thursday, September 06, 2012 3:46:39 PM

© Caterpillar Inc. 2012 All Rights Reserved.

[Data Privacy Statement.](#)